

smartWLI optical high performance profilers for wafer metrology

100x objective, stitched are 10 x 8 single scans

seize app. 1.2 x 0.8 mm²

measuring points 12000 x 8000

Upgraded!

ISO 25178 - Roughness (S-L)


S-filter (λ_s): Gaussian, 2.5 μm

F-operation: None

L-filter (λ_c): Gaussian, 0.25 mm

Height parameters

Sa 1.10 nm



BASED ON COHERENCE SCANNING (WHITE-LIGHT) INTERFEROMETRY

smartWLI

combined advantages of the smartWLI series

10x objective, stitched area 4 x4 single scans

length 5 x 4 mm

measuring points 4000 x 3200

ISO 25178 - Roughness (S-L)

S-filter (λ_s): Gaussian, 2.5 μm

F-operation: None


L-filter (λ_C): Gaussian, 0.8 mm

Height parameters


Sa 0.151 nm

Spatial parameters

Sal 0.0734 mm



COMBINES EXTREME SPEED WITH SUPERIOR RESOLUTION

**Intention:****Time is money:**

Important for all serial productions – specifically in the production of semiconductors - a fast and reliable quality control is very important to improve the yield rate and save money. The dual tube technology allows to optimize the scanning process of multiple measuring task with different speed and resolution requirements without typically limitation of optical 3d sensors / profilers.

Advantages:**SDK (software development kit):**

The SDK including libraries and the source code from test application simplifies the sensor integration in any third party system.

HD-EPSI:

High Density – Extended Phase Shift Interferometry, reduce the noise level without time consuming repeated scans of the same measuring positions down to an topography reproducibility of 0.03 nm (ISO conform rated noise level).

real time processing of image stacks using GPGPUs:

GPGPUs with up to app. 80x of the calculation power of Core i9 CPUs allows the instant data processing for shorter cycle times.

dual tube technology:

The dual tube technology allows – in contrary to zoom objectives – the instant switch between 2 tube magnifications and 2 cameras. This allow the decision between high speed measurements for geometrical feature and large area measurement of flatness and waviness or highest resolution for extreme small structures

dual cameras:

The dual camera technology combines the advantages of high resolution and 5 MP and high speed 2.3 MP (extreme speed 1.3 MP cameras). Combined with dual tube technology it provides a spatial sampling factor 3x (4x) similar to zoom objectives without the disadvantages of the zoom (contrast reduction, calibration requirements).


dual LED:

The short wavelength of blue light provide a higher optical resolution, a higher rate of scattered light on reflective surfaces and a smaller penetration depth on silicon wafers. The white light reduce the width of the correlogram. This allows to improve specific measuring tasks as thickness measurements on transparent coatings.

motorized focus – interference zone adjustments:

Specifically higher magnification objectives shows chromatic and thermic drifts between focus and interference zone. The motorized focus – interference zone adjustment allows the adjustment without manual system access – critically for high resolution measurements.


	specification
optical 3d sensor	high performance sensor for measuring stations and stand alone systems
objectives	motorized turret for up to 4 objectives
measuring principle	coherence scanning (white-light) interferometer
scanning device	piezo with close loop capacitance gauge control
topography reproducibility	0.03 nm (single scan without profile averaging)
repeatability RMS	0.003 nm (single scan without profile averaging)
optional system building kits	100 x 100 x 50 mm ³ – 300 x 300 x 100 mm ³ (xyz), tip-tilt (optional motorized)
dual camera	5 MP - 77 fps and acceleration / 2.3 MP – 169 fps (optional 1.3 MP – 935 fps)
point evaluation	massive parallel in real time on the GPGPUs
evaluation algorithms	VSI (vertical scanning interferometry) HD-EPSI (high density extended phase shift interferometry)
profile averaging	automated averaging over up to 40 single scans for noise reduction
scanning increments	variable optimization between speed and resolution



- using the GPGPU provides the calculation power
 - real time 3d calculation
 - noise reduction to measure extreme smooth surface
 - fast measurements with typically 1 ... 3 s for single scans
 - stitching of several 100 single scans
 - data quality surveillance
 - optional export of quality and infinite focus camera images
 - model based signal processing and correction


	standard objectives 2d localization				interference objectives for 3d measurements			
tube 0.5x	2.5x	5x	5x	10x	20x	50x	100x	115x **
2.3 MP	0.075	0.13	0.13	0.3	0.4	0.55	0.7	0.8
1x	8.8	22.5	9.3	7.4	4.7	3.4	2	0.7
5 MP	7.3 x 4.6	3.7 x 2.3	3.7 x 2.3	1.8 x 1.2	0.9 x 0.6	0.37 x 0.23	0.18 x 0.12	0.16 x 0.1
	3.8	1.9	1.9	0.96	0.48	0.19	0.1	0.08
	3.4 x 2.8	1.7 x 1.4	1.7 x 1.4	0.85 x 0.71	0.43 x 0.36	0.17 x 0.14	0.09 x 0.07	0.075 x 0.06
	1.4	0.7	0.7	0.35	0.175	0.07	0.035	0.03

smart WLI coherence scanning (white-light) interferometry






- coherence scanning (white-light) interferometry provide the required sub nanometer height resolution
- the extreme height resolution is – in contrary to the other mentioned principles – to a great extend independent from the magnification

smartWLI dual, 115x objective, $S_a \approx 10 \text{ nm}$, area $1.2 \times 0.8 \text{ mm}^2$ / zoom $0.12 \times 0.08 \text{ mm}^2$




smartWLI the highest speed for data acquisition and processing




Egbs


935 FPS (FULL RESOLUTION) – PROCESSED IN REAL TIME WITHOUT DELAY



z-distance from the interference maxima / nm



z-distance from the interference maxima / nm



z-distance from the interference maxima / nm


resulting noise $\sim \sqrt{\text{scanning intervall}}$

comparison of profile averaging and HDEPSI:

- profile averaging reduce the noise but the time grows proportional to the number of scans
- HDEPSI reduce the noise but reduce the scanning speed similar to the profile averaging




advantages of the HDEPSI – effective up to 2x faster than profile averaging:

- single scan without multiple objective acceleration, synchronizations of piezo and camera, 3d calculations, data averaging
- less motion blur and drift effects




comments:

- "much smaller" would be the noise Nm (->see definition in ISO 25178) $< 1/10$ of Sq
- Nm is defined as the measurement noise from the unfiltered profile and the application of λ_s should reduce the noise level further
- the topography reproducibility is a common principle to test the noise level calculating Sq out of the difference from 2 scans of the same sample with the following advantages
 - common flat surfaces can be used without a specified flatness and nature of the test specimen
 - test and evaluations are simple but have a high significance
- the smartWLI series provide a extreme small noise level for single scans without – time consuming! - continuously data acquisition over a certain time period or profile averaging over several single scans
- optional profile averaging over up to 40 single scan can be used and will reduce the noise level further



smartWLI smartSTITCH for perfect stitched high resolution measurements




standard algorithms - stitching with height compensation only




result of the standard stitching algorithms

scan 1 scan 2 scan 3


error elimination through smartSTITCH



smartSTITCH with height and angle compensation in overlapping areas



100x objective, needle for spinnerets



EVEN USING OBJECTIVES WITH A MODERATE MAGNIFICATION

SEM reference image of the black silicon surface**AFM:**

the structure slope exceed the tip angle

SEM / stereoscopic reconstruction:

the structure slope limit the possible triangulation angle,
reduce the contrast and provide only limited resolution of 3d
data

SEM side images of broken polished samples:


state of art in wafer metrology but can only provide single
profiles

Optical profilers:

the concave geometry cause multiple reflections and outliers

smartWLI nanoscan:



ATQC – advanced topographic quality control algorithms
eliminate outliers and provide high resolution data for a very
challenging surface.





.....

2.00μm



ISO 25178 - Primary surface	
S-filter (λ_s): [Workflow] S-filtered (λ_s 0.250 μm)	
F-operation: None	
Height parameters	
Sa	0.208 μm
Spatial parameters	
Sal	0.394 μm







smart WLI measurement of extreme small structures







smartWLI profile fidelity tested on pyramid structures of an AFM target
















magnification / LED	2.5x	5x	10x	20x	50x	100x	115x
1.3 MP / 0.5x tube / green	19,83	10,24	4,96	2,74	1,36	0,84	0,73
2.3 MP / 0.5x tube / green	15,63	8,14	3,94	2,23	1,15	0,75	0,64
5 MP / 0.5x tube / green	12,63	6,64	3,13	1,84	1	0,66	0,58
5 MP / 1.0x tube / blue	7,98	4,28	2,00	1,23	0,73	0,51	0,45


sample specific selection of filters and systems with the required lateral resolution coming up soon









light sources at the same height level




height differences between light sources



upper image




lower image



concave structure

- The separation of close light sources (small structures) is not physical limited if light sources (structures) are located on different height levels
- Concave structures may limit the aperture themselves – using objectives with lower aperture may reduce disturbing wall reflections





business activities

direct sales
components for integration partners
support of world-wide distribution partners

products

optical 3d sensors
optical profilers
portal measuring systems

technology

coherence scanning (white-light) interferometry
acceleration using GPGPUs

applications

surface metrology
roughness measurements
measurement of micro geometries
quality control
inline process control